FRONTMATEC

AFTER SALES // HOW TO

HOW TO ENSURE A PRECISE CUT OF THE BREASTBONE AND BELLY ON YOUR AUTOLINE CARCASS OPENER APO7 / OMEGA

Following procedure must be performed weekly.

In-and-Out measurement of breastbow guides

- 1. Place your angle on the fixpoint of the knife position A
- 2. Lean the angle along the knife and on the fixpoint on the knife holder, ensuring a fixed position of the angle position B
- 3. Pull the breastbow guides back to fit the angle and then move the angle to the other side, making sure NOT to move the breastbow
- 4. Ensure that the distance between the angle and the breastbows are the same on both sides position C
- 5. If the distance is not the same, give us a call, and we will guide you

Sideway measurement of the breastbows guides

- 1. Set your Autoline APO7 / OMEGA on Auto stop
- 2. Activate the wash position
- 3. Use a measuring tape and measure from the side of the breastbow to the center of the knife position D
- 4. The measurement from the side of the breastbow to the center of the knife has to be the same on both sides to ensure a precise cut



